



Fokker Techniek B.V.

Aviolandalaan 31, 4631 RP Hoogerheide,
P.O. Box 3, 4630 AA Hoogerheide,
The Netherlands

T: +31(0) 682 708 413
flight.ops@fokker.com

Passenger and crew services	Aircraft services
<ul style="list-style-type: none"> ➤ Customs and immigrations services ➤ Pilot briefing room ➤ Free WIFI Access ➤ Weather provisioning, Notams and flight planning ➤ Taxi services for passenger and crew ➤ Catering coordination ➤ Copy / Fax services ➤ Hotel accommodation assistance 	<ul style="list-style-type: none"> ➤ VIP Completions and modifications ➤ Aircraft MRO / Component MRO services ➤ Authorized by EASA, FAA and many others ➤ Aircraft towing with assistance ➤ * Catering Ground power / Pushbacks / Airstarter ➤ Fueling services – Jet A1 / Avgas ➤ Passengers Steps ➤ Toilet and water services
Handling information	Airport information
<ul style="list-style-type: none"> ➤ Operating hours: <i>Monday to Friday (07:00 – 15:45 UTC)</i> ➤ Flight Operations frequency: 133.030 MHz ➤ Mastercard cashmachine available ➤ Marshalling (by Fokker Techniek) ➤ Towing (by Fokker Techniek) ➤ Ferry flight crew assistance on request ➤ Aircraft types: <ul style="list-style-type: none"> - Airbus: A318, A319, A320, A321, A330, A320neo - Boeing: B737 series - ATR: 42/72 - Fokker: all types - NH-90 	<ul style="list-style-type: none"> ➤ ICAO: EHWO ➤ IATA: WOE ➤ Latitude: 51.449092 ➤ Longitude: 4.342031 ➤ Elevation: 63 feet (19 meters) ➤ Runways: 07-25 ➤ Longest runway: 7996 x 148 feet (2437 x 45 meters) ➤ Type airport: Military ➤ RSTD: PPR ➤ Types of Traffic Permitted: IFR/VFR ➤ Time zone: UTC+1 (DST +2) DST: Last Sunday in March to last Sunday in October ➤ Rapcon west: 123.580 MHz ➤ Woensdrecht Tower: 120.430 MHz ➤ Woensdrecht Ground: 121.680 MHz ➤ Category I ILS ➤ Full Fire & Rescue support Cat. 7 (standard) ➤ Approach plates available on request